

# INDASH by PANAVISE®

I-75142-306

Page 1 of 1

## MOUNTING LOCATION:

Right side of radio cavity KR

## TOOLS REQUIRED:

Dash Tool, Hook tool

Phillips screwdriver

## HARDWARE INCLUDED:

None

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75142-306

MFG: KENWORTH

MODELS & YEARS:

T600, T660, T800 06-2014

W900, C500 06-2014

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With hook tool, remove the bezel that goes from the right of the radio, gauges and switches all the way to the drivers door. There are a total of (13) clips holding this bezel in place.

STEP #2 With Phillips screwdriver remove the upper right screw on center gauge panel. Lift up the gauge panel and slide InDash by PanaVise Mount under panel and over screw hole on upper right of gauges. Replace the screws, making sure the side of the mount is flush with the dash before trying to put the bezel back in place.

STEP #3: Replace the bezel starting from the drivers door side and working to the right side. The InDash by PanaVise Mount should be flush to the dash before the bezel can be installed by the mount.



InDash installed under panel

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing location



02-20-13